PLAN

DETAIL A

ROOT ANCHOR ITEM#	ROOT BALL & CONTAINER SIZE	ANCHOR INSTALLATION DEPTH	QUANTITY & ANCHOR SIZE
15-BG	10 / 15 Gallon or 17" root ball	12 - 18" Minimum Depth	3 - V68 Anchors
30-BG	20 / 39 Gallon or 22" root ball	18 - 24" Minimum Depth	3 - V68 Anchors
45/65-BG	45 / 65 Gallon or 27-30" root ball	24 - 30" Minimum Depth	3 - V68 Anchors
100-BG	95 / 100 Gallon or 36" root ball	30 - 36" Minimum Depth	3 - V68 Anchors
150-BG	150 Gallon or 42" root ball	48" Minimum Depth	3 - V68 Anchors
200-BG	200 Gallon or 48" root ball	48" Minimum Depth	3 - V88 Anchors
300-BG	300 Gallon or 58" root ball	48" Minimum Depth	3 - V88 Anchors
CUSTOM-BG	Root Balls larger than 60"	TBD	

SECTIONS

STEP 1:

- SET TREE IN PLANTING PIT
- PLACE ANCHOR WITH RING SIDE DOWN AGAINST TOP OF ROOT BALL
- CENTER ROOT ANCHOR'S INNER RING(S) AROUND TRUNK OF TREE
- ALIGN DRIVE ROD AS CLOSE AS POSSIBLE TO OUTSIDE EDGE OF U-BRACKET

STEP 2:

- DRIVE ANCHOR STRAIGHT DOWN INTO UNDISTURBED SUBBASE SOIL
- SEE CHART FOR RECOMMENDED DEPTHS PER TREE SIZE

STEP 3:

- REMOVE DRIVE ROD
- REPEAT STEPS 1 & 2 FOR ALL THREE (3) ANCHOR LOCATIONS
- PULL BACK ON STRAP APPROXIMATELY 3' FOR THE V-68 ANCHOR, OR 6' TO 7' FOR THE V-88 ANCHOR TO SET ANCHOR INTO A HORIZONTAL OR LOCKED POSITION. A FULCRUM MAY BE REQUIRED TO ASSIST IN SETTING THE ANCHOR.
- PLACE "S" HOOK OVER THE END OF THE U-BRACKET
- PULL STRAP UP VERTICALLY UNTIL ROOT ANCHOR RINGS BITE INTO THE TOP OF THE ROOT BALL AND U-BRACKETS ARE SETTING FLUSH ON TOP OF THE ROOT BALL
- TIE EXCESS STRAP OFF TO THE U-BRACKET ALLOWING ENOUGH REMAINING STRAP TO ADJUST TREE, IF NECESSARY

TREE STAKE SOLUTIONS, LLC.
9973 FM 521 Road
Rosharon, Texas 77583
www.treestakesolutions.com

Phone: 281-778-1400
Mobile: 903-676-6143
Fax: 281-778-1425